

Monsoon HVHT

Monsoon Remote Humidistat and Timer



Surface mounted fan controller. White, ABS thermoplastic construction. Suitable for domestic use.

IP42

• 3 Year Manufacturer's Guarantee (T&Cs Apply)

Model No: 1361



INSTALLATION INSTRUCTIONS FOR THE 404372 REMOTE HUMIDISTAT FAN TIMER

Please read these instructions before installation.

Switch off mains supply before making any electrical connections, if you are in any doubt about the installation consult a qualified electrictian. This appliance may be used by children aged from 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintanence shall not be made by children without supervision.

Precautions must be taken to avoid the back-flow of gases into the room from the open flue of gas or other open-fire appliances when mounted in outside walls or windows.

This controller must be disconnected from electical power before any maintenance or adjustment is carried out.

Thank you for choosing the 404372 Remote Humidistat Fan Timer. These Instructions are included for your guidance.

The 404372 Remote Humidistat Fan Timer suitable for use with any single or combination of fans without shutters, providing the total electric load is not more than 200W. This control unit combines an over run timer activated by a switched live connection and an automatic humidistat.

 The timer is user adjustable to provide a full power run-on period between approximately 1 minute and 60 minutes.

The automatic humidistat activates the extractor fan when the ambient humidity exceeds a user settable threshold.

- The humidity threshold is user adjustable between approximately 20% RH (always on) and 90% RH (rarely on)
- IMPORTANT: A double pole switch must be used, having a contact seperation of at least 3mm in all
 poles, and a fuse rated at 3A. All wiring must be fixed securely. The cable to the fan must have a
 minimum of 1 square millimetre cross section and should not exceed 2000mm in length, excessive
 length could possibly cause radio interference. All wiring must comply with current IEE regulations.

Switch off mains supply before making any electrical connections.

• IF IN ANY DOUBT PLEASE CONTACT A QUALIFIED ELECTRICIAN.

The remote humidistat must be installed outside

zones 0. 1 and 2 - see diagram.





